Winlink Setup via Digirig and VARA FM

April 6, 2025

This document was created by Greg Singer, K3VLR. If you have any questions, please contact me at k3vlr@arrl.net.

Winlink Settings:

- Open "Winlink Express"
- o Click "Settings"
- Select "Winlink Express Setup"
- Make sure the following fields are filled out
 - My Callsign
 - My Password
 - Password Recover E-mail
 - My Grid Square

My Callsign: K3	/LR My Password: •••••••• (Case sensitive)	••
Callsign suffix (optional):	(Used for country code) Change pas	sword
Password recovery e-mai	k3vlr1@gmail.com	
(Non-Winlink e-mail addre	ess where lost password will be sent when requested	i)
Remove Callsign	Request password be sent to recovery e-mail]
Remove Callsign	Request password be sent to recovery e-mail]
Remove Callsign	Request password be sent to recovery e-mail I Addresses Add Entry Remove Entry]

- Click "Update" to save
- o To switch from Telnet to VARA FM P2P
 - On the main Winlink Express window find "Open Session" on the top right.
 - Click the drop down menu next to "Open Session"
 - Select "VARA FM P2P"
 - Click "Open Session"
 - Winlink Express 1.7.19.0 K3VLR
 - K3VLR Settings Message Attachments Move To: Saved Items Delete Open Session: Vara FM P2P Logs
 - VARA FM will launch

VARA FM Settings:

- Click "Settings"
- Click "VARA Setup"
- Set "Command" to "8300"
- Set "FM System" to "Narrow"
- Set "Retries" to "6"
- Click "Close"

CP Ports:	FM System:	-VARA Licens	es
Command	NARROW -	Callsign:	Registration Key:
8300	Digipeater:	K3VLR	*****
Data		Callsign:	Registration Key:
8301	Retries:		
	6	Callsign:	Registration Key:
	Allow VARA check for updates	0.00	D I I I
		Callsign:	Hegistration Key:

VARA FM PTT: (Digirig Lite Only)

- Click "Settings"
- Click "PTT"

•

- Select "RA-Board"
- Click "Close"

PTT 🛅

CAT COM CA-Board CVOX

VARA FM PTT: (Digirig Mobile Only)

- Click "Settings"
- Click "PTT"
- Select "COM"
- Select "Com Port"
- Click "Close"



VARA FM Sound Card (For the Digirig device):

- Click "Settings"
- Click "Sound Card"
- Under "Device Input" select "Microphone (USB Audio Device)"
- Under "Device Output" select "Speakers (USB Audio Device)"
- Under "PTT" select "RA-Board-1"
- Under "Channel" select "L"

Microphone (USB Audio Device)	
Device Output	PTT
Speakers (USB Audio Device)	▼ RA-Board-1
	Channel
Auto	Channel CLCRCL
Auto Turne	Channel
	Channel CL CR CL+
Auto Tune Drive level:	Channel C L C R C L+
Auto Tune Drive level:	

Click "Close"

Digirig audio settings for Windows 10 and 11:

- Press Windows+R to open the Run window
- Type "control"
- Click "OK" or press enter
- In the top right-hand corner click on "Category".
- Select "Large Icons"
- Scroll down and click "Sound"
- Click the "Playback" tab
- Select "Speakers USB Audio Device"
- Click "Properties"
- Click the "Levels" tab
- Under Speakers move the slider to the left until it shows "20"
- Click "OK"
- Click the "Recording" tab
- Select "Microphone USB Audio Device"
- Click "Properties"
- Click the "Custom" tab
- Uncheck "AGC"
- Click "OK"
- Click "OK" again
- Close the Control Panel

Radio settings for your HT:

- \circ Enter the simplex frequency of 145.030 MHz
- o Set Radio to "Wide"
- o Set squelch to "Zero"
- Set power level to "Low" (Since we will all be in the same room)
- Adjust volume on radio so "Audio Input" is in the green:



0

Team up with a partner and test your setup:

- From VARA FM Click "Settings"
- o Click "Sound Card"
- o Click "Auto Tune"
- Under "Calibrate with" enter your partners callsign
- o Click the button to the right to start transmitting

Calibrate wi	ith
K I3X	.

Drive Level Calibration



- Once it is done you will receive a Calibration Report
- Review the settings from the Calibration Report. You may need to increase or decrease the audio output of the Digirig.
- Once it successfully calibrated you will receive an "APPROVED" screen like the one below:

👋 Drive Level Calibration	×
Calibrate with: KE80K0-4	٩,
Drive Level: -18 dB	
S/N: +20.6 dB	
VU: -13 dB	
APPROV	<u>(R</u>

Close

0

0

• Please note: If it does not say approved it may not work 100% of the time. Be sure to adjust settings until it says "APPROVED".

A good troubleshooting tool is to monitor the audio from your HT on the computer speakers. This is not needed if everything is working:

- o Go to the Control Panel
- Click on "Sound"
- Click the "Recording" Tab
- Select "Microphone (USB Audio Device)"
- Click "Properties"
- o Click the "Listen" tab
- o Check the box "Listen to this device"
- Click "OK"

0

o Click "OK" again

c	Liston	6 . I			11		
General	Listen	Custom	Levels	Advand	ed		
You ca this M feedb	in listen i licrophoi ack.	to a portat ne jack. If j	le musi /ou con	c player inect a n	or othe nicropho	r device t one, you i	hrough may hear
🖸 List	ten to th	is device		=>	0	I	
Playba	ack throu	gh this de	vice:				
Defa	ult Playba	ack Device				~	
Pow	er Mana	gement					
0	ontinue	runnina w	hen on	battery	power		
OD	isable a	tomaticall	y to sav	e powe	ŕ		

For this setup I am using a Dell laptop running Windows 11 and a Kenwood TH-D72 handheld radio. I also purchased the items listed below:

- Digirig Lite: <u>https://digirig.net/product/digirig-lite/</u>
- Digirig cable for Baofeng/Kenwood/Wouxon HT: https://digirig.net/product/baofeng-cables/
- VARA FM: <u>https://rosmodem.wordpress.com/</u>
- You can use the free version of VARA FM if you are using P2P. In order to use the digipeater function you must have the paid version. I emailed the author, and he confirmed that a single VARA license can be used for VARA FM and VARA HF. You can also use the license on your desktop and your laptop computers.

Configure Winlink and VARA FM to work with the K3ACS-4 Digipeater: (This requires the paid version of VARA FM)

- On the main Winlink Express window find "Open Session" on the top right.
 - \circ $\,$ Click the drop down menu next to "Open Session"
 - o Select "VARA FM Winlink"

•

X

- In Vara FM Winlink session.
 VARA FM will launch
- In the VARA FM Winlink Session window click "Direct"
- Select "Digipeater"

0

- o In the first box enter KE8OKO-4
- o In the second box enter K3ACS-4
- o Click "Start" to begin transmission

▼ KE80K0-4	Hates I		2 m 2 m 2 m 2 m 2 m 2 m 2 m 2 m 2 m 2 m		
1.200.110	via KJACS-4	\approx	Freq.: ().000 Range:	Bearing: 000
		✓ Sele	ct Add to favorites	Remove from favo	rites
625 0 je JVGN98UX1B6X 25, Time: 00:26, byte U 7 bytes received	es/minute: 506				
	: 1071 Disconnecter 625 0 je JVGN98UX1B6X 25, Time: 00:26, byte U 7 bytes received	: 1071 Disconnected Time to next Autoc 625 0 je JVGN98UX1B6X 25, Time: 00:26, bytes/minute: 506 U 7 bytes construed	 Sele 1071 Disconnected Time to next Autoconnect = D 625 0 ge JVGN98UX1B6X Z5, Time: 00:26, bytes/minute: 506 U Totes received 	 Select Add to favorites 1071 Disconnected Time to next Autoconnect = Disabled 625 0 ge JVGN98UX1B6X Z5, Time: 00:26, bytes/minute: 506 U 	 Select Add to favorites Remove from favo 1071 Disconnected Time to next Autoconnect = Disabled 625 0 ge JVGN98UX186X 25, Time: 00:26, bytes/minute: 506 U

 By following these steps, you are sending your message to the K3ACS Digipeater. The Digipeater then sends the message to the KE8OKO Gateway in Poland, Ohio. The Gateway is connected to the Internet. The Gateway will deliver your message to any email address. The Digipeater and the Gateway are on the frequency of 145.030 MHz.